

- **Project:**

H2 5-10K T2

- **Accessory packaging information:**

1. 30204706/Three core AC connector sleeve;
2. 30204707/Five core AC connector sleeve

- **Installation sequence (As below)**

1. Insert the cables and tighten the locknut in each cable.
2. Install the protective covers to the cable connectors.
3. Tighten two screws to secure each connector tightly.

