

- **Project:**
R5 0.7-3K-S1/ R5 3-6K/ R5-3-12K-T2

- **Accessory packaging information:**

1. R5 0.7-3K-S1/ R5 3-6K
--30204706/Three core AC connector sleeve;
2. R5-3-12K-T2
--30204707/Five core AC connector sleeve

- **Installation sequence (As below)**

1. Insert the cables and tighten the locknut in each cable.
2. Install the protective covers to the cable connectors. (Caution: choose right sleeve model according to machine model)
3. Tighten two screws to secure each connector tightly.

